

Instruction Manual

15.4-inch TFT LCD Monitor

VIEW®
Mobile Entertainment Solutions
T156IR




HAZARD WARNING:
PLEASE DO NOT OPERATE THIS
UNIT UNLESS VEHICLE IS PARKED
IN SAFE AND LEGAL AREA

T156IR

15.4 " TFT Color Monitor

Diagram slice



FUNCTION KEY

- | | |
|-------------------|-------------------|
| 1.remote control | 6.Analog increase |
| 2.power switching | 7.Audio IR |
| 3.V1/V2 switching | 8.ligh switching |
| 4.Analog decrease | 9.open switching |
| 5.Menu | |

Type:TFT LCD

Display size:15.4 "

Display format: 16:9

Power:About 15W

Power supply:DC 12v

Video:Dual video input


System:PAL/NTSC(Auto switching between the two systems)

Pixel: 1024(H) x RGB x 760(w)

Brihgt: 300:1

Function:Installed on the automobile ceiling.

Blue Screen:Video signal disappears,with automatic appearance of blue screen.



- 1.power switching
- 2.V1/V2 switching
- 3.Analog decrease
- 4.Analog increase
- 5.Menu
- 6.Mode Select (RESET)

